

FITTING INSTRUCTIONS

VW MK5 GOLF R32 : FRONT SPLITTER

FITTING KIT

PLEASE NOTE:
BUMPER REMOVAL RECOMMENDED
FOR BETTER FITMENT

a

**M6 BOLT
40mm LONG**

X 3

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER



b

**M6 BOLT
30mm LONG**

X 6

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER

