

# FITTING INSTRUCTIONS

## VW GOLF MK7 R WAGON: REAR VALANCE KIT

### FITTING KIT

**a**



**M6 BOLT  
25mm LONG**

**X 8**

PLEASE NOTE:  
DRILLING REQUIRED  
TO FASTEN TO BUMPER

**b**



**M6 BOLT  
30mm LONG**

**X 2**

PLEASE NOTE:  
DRILLING REQUIRED  
TO FASTEN TO BUMPER

