

FITTING INSTRUCTIONS

VW SCIROCCO R FACELIFT : REAR VALANCE KIT

FITTING KIT

a

**M6 BOLT
40mm LONG**

X 4

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER



b

**M6 BOLT
25mm LONG**

X 6

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER

