

## **Slimfit<sup>™</sup> ONT** | INSTALLATION MANUAL

## **Product Description**

SlimFIT™ ONT FPP-01-W-A9 is designed for popular ONTs including the Adtran® (411), Calix (803G), Ubiquiti® (U FIBER). Custom mounting plates can be made to support other ONTs.



## **ONT Installation Procedure**

Step 1: Remove cover from SlimFIT™ ONT.

Step 2: Locate holes on the mounting plate for your ONT (see Figure 1).

Adtran ——

Calix —



Figure 1

1 (of 2)

## **ONT Installation Procedure**

If using the Ubiquiti® ONT, attach the included Ubiquiti® holder to the mounting plate (see Figure 2).



If using a different brand of ONT, attach the included hook-and-loop to the mounting plate to secure the ONT (see Figure 3).

Figure 2



Figure 3

Step 3: Attach your ONT to the mounting screws.

If using the Ubiquiti® ONT slide the ONT into the holder (see Figure 4).



Adtran® (411)



Calix (803G)
Figure 4



Ubiquiti® (U FIBER)

2 (of 2)

<sup>\*</sup> Total Cable Solutions is not affiliated with Adtran®, Calix or Ubiquiti®. All product names are trademarks or registered trademarks of Adtran®, Calix or Ubiquiti®.