

Installation Guide



2011 GM Duramax Trucks

Part P2040
6.6L DIESEL

1. The first step is to find your Fuel Sensor. On your 2011 Duramax the Fuel Pressure Sensor can be found on the driver's side of the engine just behind the fuel rail. If you are having trouble locating it please use the below picture. The Plug should match the plug on our supplied harness

2. Once you have located the Fuel Pressure Sensor, disconnect your stock harness and connect the supplied DiabloSport harness to the fuel pressure sensor and back into the factory connector.

3. Locate a suitable location to mount the Extreme PowerPuck using the supplied zip ties and/or Velcro. Keeping the Puck away from hot surfaces and moving parts is recommended.

4. Now plug the supplied harness into the Extreme PowerPuck. Please be sure that no wires hang down and are free from moving parts.

5. Route your Diablo Dial wire Route from inside the cab through the firewall to the Extreme PowerPuck and plug it in.

6. You now have the option to mount the Diablo Dial on your dash in a convenient area. Please be sure to secure the wire and keep it away from any moving parts.

FUEL SENSOR PLUG



Chevrolet Silverado HD

2011 Duramax Diesel 6.6L V-8 Turbo (LML)

6.6L DIESEL ENGINE