


## INSTALLATION INSTRUCTIONS

### PRODUCT: ALL LIGHTS ON™

FPE-2020-5  
January, 2020  
Page 1 of 1


**INSTRUCTIONS FOR:** 2018-2019 GM Equinox  
**ESTIMATED INSTALLATION TIME:** 10-15 minutes

**STEP 1:** The Body Control Module (BCM) is located on the passenger side, under the center console cover in the foot well. Remove the single 7mm screw and gently pull the panel outwards along the edges and remove it from the vehicle. The BCM will have 7 connectors, each a different color. You will be removing the brown connector.




**STEP 2:** Disconnect the brown connector from the BCM. Remove any tape or wrap to expose enough of the wires to install the All Lights On™ module (3-4 inches).

**STEP 3:** Locate pin 10 (fog lamp control). The wire is *brown or tan with a white stripe*. From the bottom right side of the connector, count over 5 pins and up 3 pins to locate the wire. Route this wire through the circuit board and connection labeled "fogs".



Pin 10, Fog Light Signal



Pin 18, High Beam Signal

**STEP 4:** Locate Pin 18 (high beam control). The wire is *brown or tan with a purple stripe*. From the bottom right side of the connector, count over 3 pins and up 2 pins to locate the wire. Route this wire through the circuit board and connection labeled "highs".

**STEP 5:** Position the cover over the wires and squeeze it downward with a pair of pliers to force the wires into the insulation displacement prongs. Install the brown connector back into the BCM.

**NOTE:** The connector cover is a one-time use part. Double check the pin locations before installing the cover, it cannot be removed and re-used.

**Operation:** Low beams and fog lights will operate normally, when high beams are activated, the fog lamps and low beams will remain on.

**NOTE:** For dual filament bulbs - only your fog lamps will remain activated when the high beams are turned on with the All Lights On™ module.



Route wires as shown



Install cover to seat wires