

Bendtsen's Speed Gems Transmission Adapters

EMAIL: sales@transmissionadapters.com PHONE: (763) 767-4480



FO1001601 Ford 429/460 to Chevy Automatic Transmission

Make sure you clean all surfaces when mating these parts together. Always check bolt clearances. We try to make everything as simple as possible to help you, but the ultimate responsibility as to the assembly of the kit is up to the installer. Check and recheck as you go. We can't foresee every change or modification that could possibly occur in the building of a custom vehicle. Especially when we are dealing with 50-year-old motors.

Materials Included

- (1) Bell housing Small block Ford to early transmission (1948 and older)
- (1) Block Plate 6 bolt small block Ford to early trans
- (1) Pilot Bushing Small block Ford to early transmission 1948 and older
- (6) SHCS 7/16-14 X 1 1/4
- (3) HCS 5/16-18 X 1/2 YZ 8
- (3) USS FLAT WASHER 5/16 YZ 8
- (8) HCS 3/8-16 X 1 YZ 8

While performing this installation, please remember a few simple rules.

- 1. Install all bolts before tightening in a particular sequence
- 2. Use Loctite and torque bolts where applicable. Never force anything
- 3. Lubricate both threads
- 4. Trial fit everything to make sure it will fit. See rule #2.

Installation Intructions

Bendtsen's Speed Gems Transmission Adapters. 806H S. Division St., Waunakee, WI 53597 sales@transmissionadapters.com (763) 767-4480

Copyright © 2002 Bendtsen's Transmission Center Inc. All rights reserved.