



Place the sign on the post, a minimum of one inch from the top of the post. Mark the three mounting holes.



Pre-drill the three mounting holes using a 1/4" drill bit.



Place the color wheel on the post aligning the center hole. (Do not attach.)



Use a 7/16" nut spacer/stand-off between the post and the back side of the outer sign at both the top and bottom holes. Attach sign to post using 5/16" x 2 1/2" lag screw with flat washer.



Be sure to not over tighten center mounting lag screw. Color wheel should turn without resistance.



Use the pin lock to lock category settings using the aligned holes in the upper right side as you are facing the sign.