



CRUZBIKE T50

SEAT ASSEMBLY

1. Install the seat base to the base mount as shown, using 4 of the shorter M5 bolts. The washers and nuts go on the underside. It is recommended to align the bolts and base so it is as far forward to the front of the seat as possible to start.

2. Install the rear seat bracket to the seat back as shown using 2 M5 bolts, washers, and nuts.

3. Install the seat back to the seat base. There are 4 black rubber bushings that go in the holes of the base and back. Using the long M5 bolts, assemble the seat halves placing a plastic spacer between the rubber bushings as shown in the picture. Note: you will have two plastic spacers left over as spares.

4. The seat is now ready to install on the frame. When installing the rear seat strut assembly, it is important to loosen the bolts that hold the clamps midway up the stay assembly to allow for proper alignment of the seat back attachment and where the seat strut assembly attaches to the frame.

