

Case Study Bentwood V-Leg Bed Assembly

Legs, L-bracket to base:
x15

L-bracket to headboard:
x9

Note: Phillips-head screwdriver, Flat-head screwdriver and Socket Wrench not included.

x6

x3

x3

x15

MODERNICA
www.modernica.net