



FLY ROD COMPANY

### Line Recommendations for Spey Rods

Model	Length	Line Weight	Grain Window	Skagit	Scandi	Intergrated
7125-3	12' 5"	6/7/8	380-530	510	450	6/7
7133-3	13' 3"	6/7/8	480-600	540	510	7/8
8133-3	13' 3"	7/8/9	530-700	570	540	8/9
8139-3	13' 9"	7/8/9	540-730	600	560	8/9
9143-3	14' 3"	8/9/10	550-740	630	540	8/9
9149-3	14'9"	8/9/10	550-740	630	600	8/9
10130-3	13' 0"	9/10/11	630-800	720	640	10/11
10150-3	15' 0"	9/10/11	630-800	760	680	10/11
4114-4	11' 4"	3/4/5	230-350	330	300	4/5
5115-4	11' 5"	4/5/6	290-400	390	330	5/6
6128-4	12' 8"	5/6/7	360-500	450	390	6/7
6139-4	13' 9"	5/6/7	360-500	450	390	6/7
7115-4	11' 5"	6/7/8	450-570	540	510	7/8
7117-4	11' 7"	6/7/8	420-550	480	420	6/7
7127-4	12' 7"	6/7/8	400-550	480	420	6/7
7134-4	13' 4"	6/7/8	420-570	540	480	7/8
7139-4	13' 9"	6/7/8	420-570	510	450	7/8
7141-4	14' 1"	6/7/8	450-550	510	480	7/8
8115-4	11' 5"	7/8/9	450-570	560	510	7/8
8128-4	12' 8"	7/8/9	450-600	540	500	7/8
8134-4	13' 4"	7/8/9	450-600	570	510	8/9
8139-4	13' 9"	7/8/9	480-630	570	510	8/9
8142-4	14' 2"	7/8/9	480-650	570	540	8/9
8152-4	15' 2"	7/8/9	500-700	600	560	8/9
9119-4	11' 9"	8/9/10	550-660	600	560	9/10
9129-4	12' 9"	8/9/10	510-630	600	550	8/9
9135-4	13' 5"	8/9/10	550-700	660	600	9/10
9145-4	14' 5"	8/9/10	550-700	630	570	9/10
10129-4	12' 9"	9/10/11	600-750	720	660	9/10
10153-4	15' 3"	9/10/11	600-800	720	640	10/11
11155-4	15' 5"	10/11/12	640-850	800	680	10/11
8121-5	12' 1"	7/8/9	460-600	540	480	7/8
8133-5	13' 3"	7/8/9	480-600	570	510	8/9
9135-5	13' 5"	8/9/10	510-660	600	540	8/9
9144-5	14' 4"	8/9/10	550-690	630	570	8/9
10148-5	14' 8"	9/10/11	630-750	720	660	9/10
6104-4	10' 4"	6	210-290	260	230	DT6F
7104-4	10' 4"	7	270-350	340	300	DT7F
8104-4	10' 4"	8	335-410	390	350	DT8F

These recommendations should be considered a starting point when selecting lines. Individual tastes in action and load, along with casting proficiency will have a bearing on what works best for you. If you have questions or would like more specifics please give us a call.