

ATV CABIN ASSEMBLY, INSTALLATION, AND CARE INSTRUCTIONS

CABIN ASSEMBLY

1. Spread the fabric shell on the floor with the outside down.
2. Slip the two "L" shaped tubes with two bends in them into the fabric sleeves labeled (A) on either side of the front windshield. The top of the "L" should point to the inside of the fabric shell. Now join the two (A) tubes together at the bottom by pushing the crimped end of one (A) tube into the open end of the other (A) tube.
3. Slide the two "L" shaped (B) tubes into the fabric sleeves labeled (B) along the back window and then join the two (B) tubes together of the bottom.
4. Insert the inside ends of the two (A) tubes and (B) tubes into the two (C) tubes. Make sure that the three holes in each (C) tube face in towards the center of the fabric shell.
5. Insert the three roof rods (D) into the three fabric sleeves (D) between the front and back windshield and insert the ends of the roof rods into the holes in the (C) tubes.
6. By the center of each roof tube (C) there is a hook-and-loop strap to secure the roof to the frame. Pull the hook-and-loop strap over the top of each tube (C) and attach to the corresponding tab on the other side of the tube.
7. Secure the fabric cover to the frame bottom with the four hook-and-loop straps along the front and back.



INSTALLATION

8. Locate the four clear polyethylene protection bushings. Slip one bushing onto the bottom of each of the (A) and (B) tubes so that there are two bushings on both the front and back.
9. Gently lift your assembled ATV Cabin onto your ATV so that it rests on your front and rear luggage racks. Your ATV Cabin will usually be large enough to enclose one of your luggage racks. Reposition the clear protective bushings so that they are between your luggage rack and the ATV Cabin frame.
10. Use the four U-bolts and plates and the eight nuts and lock washers to secure the ATV Cabin frame to both luggage racks.
11. Secure the two leg protection flaps (on the inside front) to your ATV with the hook-and-loop glue tab on the bottom of the flap. The flaps can be repositioned later with these hook-and-loop tabs.

CARE AND USE

You can roll up the two doors – just secure them with the two snap straps at the top of each door. Don't roll up the doors in temperatures below freezing as the vinyl windows could crack.

Your ATV Cabin can be cleaned with warm water and a SOFT cloth. DO NOT USE SOAP OR ANYTHING ABRASIVE WHEN CLEANING THE CLEAR VINYL – it can scratch.

WARRANTY

This ATV Cabin is factory warranted for workmanship and materials for a full 1 year after your purchase. This warranty assumes normal use and conditions and does not include chemical damage to the cover, collisions, window scratches, or misuse. Not for use at speeds over 25 m.p.h.

