

# **Specification and Application Sheet**

## **THERMA-GRIP TAPE**

#### **Description**

White conformable slip and heat resistant self-adhesive tape for Grab Rails. **Size** 101mm wide

### **Application Instructions**

- 1 Make sure the surface is clean, dry, smooth and above the 4 °C minimum application temperature.
- 2 Repair or replace any broken or damaged surface.
- Wipe Surface with a solvent to remove grease or oil residue. Isopropyl Alcohol, Acetone or Methylated spirits can be used. It is recommended that several wipes with a new clean soft cloth each time are utilized to attain a clean surface.



- 4 Apply the tape to the top surface, centering the tape so that the join will be on the underside of the rail. Work your way along the rail removing the adhesive protective sheet as you progress.
- 5 Ensure that pressure is applied to the final join areas with a roller or tapping with a rubber mallet to ensure a good edge seal is formed.

#### **Maintenance Instructions**

- 1. To maintain product effectiveness the application should be inspected periodically to ensure serviceability.
- 2. Ensure that tapes are kept free of dirt and other residues that might impair functionality.
- 3. Brush the surface with a soft brush or damp soft cloth to remove residue.



7 Barrinia Street Slacks Creek QLD 4127 Phone: (07) 3290 4007 Fax: (07) 3290 4001

Email: info@bendtech.com.au web: ww.bendtech.com.au