

2013-2015 4 pack harness: t-tap version.

You will need to access the passenger footwell area to locate the 30 pin connection point.

Remove passenger side dash board trim.



Remove inner sill plate by gently pulling out and up..



Remove side panel trim by releasing both the upper and lower trim clip.





Wiring connection.

Wiring can be done on either half of the connector. There are 3 connections points

A7- Black wire which is located in between a brown/white wire and a pink wire. Connect the black wire on the 4 pack harness to this black wire

A9- Red/white wire which is located between the pink wire and a purple wire. Connect the red wire on the 4 pack harness to this red/white wire

B5- Green wire which is located on the opposite side of the plug and is located between a tan/black wire and a dark blue wire. Some cars may not have the tan/black wire in the harness for reference. Connect the green wire on the 4 pack harness to this green wire.

