

Main harness connection will be made on the passenger side of the truck.

Inline portion of the harness goes inline with the passenger side main headlight plug. This plug is located on the bottom side of the headlight. For those with smaller hands you will be able to access the plug from the top of the truck, for those with bigger hands you will need to access it thru the passenger wheel well. To do this simply remove the lower screws from the liner assembly and move the liner to the side. Once out of the way you will see the 8 pin headlight connector that is a match to our harness. Slide the red tab back and then depress on the release portion to remove it from the headlight. Once removed you can plug our harness into the headlight and other end into the factory harness.

Power connection: The ring terminal wire connects to battery positive.

The relay/relays can be mounted in a location of your choice. They do not need to be grounded so they can be mounted with a tie-strap if you like. Please try and mount them in an area where they will not get wet. The relays are water resistant but not waterproof.

The fog light leads can than be run to the respective fog light assembly.

Thank you
Gen5DIY