

-Turn steering wheel all the way to the left.

-Remove the 3 torx screws front the passenger side fender liner to the front edge of the bumper.

- With the screws removed you can easily pull the fender liner back and gain access to the bumper harness. Locate the bumper harness as shown in picture.



-Disconnect the harness and install our harness inline

- Reinstall the fender liner screws

