

Foot well harness non-switched.

1- Remove RH sill plate by lifting up on plate



2- Remove RH Dash Trim using a suitable plastic pry tool.



3- Remove RH kick panel by lifting up and out.



4- Locate the flat 30 pin connector on the kick panel area.



5- Locate the black wire located in A7. For reference A6 is brown/white and A8 is pink. Tie the loose black wire into the black wire in A7

6- Locate the gray wire in B7. For reference B6 is dark blue and B8 is dark green. Tie the loose red wire into the gray wire in B7.

7- If you only want your foot well lights to come on when you open the door your connections are done. If you want them to also come on automatically at night you will need to connect the other end of the harness to the console cap harness which is located in the front of the upper console trim plate. Remove the upper console trim plate by gently prying up on the plate and lifting up. Once the plate is loose you will notice the console cap harness in the front of the plate. Disconnect this harness and install our harness inline and re-connect.