

## Gen6 Radar Detector Harness

Tools needed: Plastic Pry Tool

Step1: Drop down the overhead console by inserting your pry tool and releasing console from headliner



Step 2: Unplug all connectors on top of overhead console and set console aside.

Step 3: Install our harness inline with the harness that connects to the airbag light. Once connected you can route the phone cord cable reward thru the slot in the headliner.



Step 4: Reconnect all connections and reinstall overhead console.