

Step 1: After installing your new headlamps into the car, you are going to simply plug our connector inline with each existing headlamp connector and run the other connector behind the passenger side headlamp and down into the front bumper area.

Step 2: Turn your steering wheel all the way to the left to gain access to the passenger side wheel well.

Step 3: Remove the 3 (T-20) torx screws from the wheel well. Move the liner out of the way to gain access to the forward lamp harness

Step 4: Locate the forward lamp harness connector and unplug and install our connector inline with this connector.



Step 5: Reinstall the wheel well liner.

Step 6: For those that selected the halo's always on function. Locate the #15 fuse slot in the under hood fuse block and remove the 5 amp fuse and install the 5 amp fuse into the vacant add-a-fuse cavity. Install the add-a-fuse into the #15 fuse slot.

Step 7: Verify operation of headlamps. In daytime mode your existing foglamps should now be your DRL's. In order to verify daytime function you will either need a helper or park your vehicle in front of a window. Make sure the car is running and is in bright daylight, emergency brake released, and automatic's must be in gear. This will put the vehicle in daytime running light mode.