

Frameless mirror part 2

Step 10: Remove outside trim around radio using plastic pry tool, for models with heated seats you will need to disconnect the connectors on the back side of the trim



Step 11: Remove radio faceplate. Using 7 mm nut driver remove 4 screws





Step 12: On the backside of the screen you will notice a black connector that matches the other half of the Gen5DIY harness, unplug this connector and install our harness inline



Step 13: Route green wire over to pocket and drop down behind driver's side knee bolster



Step 14: Reinstall radio screen and trim

Step 15: Connect both halves of the green harness together



Step 16: Reinstall any remaining trim items. Start engine. On-star LED's should be lit, if on-star is activated you can try calling it for testing purposes.

Thank you on behalf of Gen5DIY

