

Fuse connection. Locate and remove the 5 amp fuse from circuit #15 and install the removed 5 amp fuse into our fuse assembly so that our assembly now has 2 fuses in it. Then install our fuse assembly back into # 15. Each end of the harness plugs inline with the headlight and the original headlight harness. To route the wire from side to side we like to remove the upper radiator mount bolts and simply tuck the harness under the mounts and then re-install.

