## Tahoe/Suburban Fog Light Harness

1- Remove the air cleaner assembly. Remove the upper lid and intake tube from the air cleaner assembly. Remove lower half of air cleaner by simply pulling up as it is held in with rubber grommets.





Step 2: :Disconnect the connector from the passenger side headlight. There may be a red, safety, tab on the connector. Remove the tab and then depress and pull the connectors off. Then install our harness inline with the headlight and the original truck harness.



Step 3: Pass the fog light wires down to the bumper area. Once they are down there you can route them to each fog light assembly.

- Step 4: Connect the ring terminal wire to the battery positive post
- Step 5: The relay does not have to be grounded so you can simply mount it to the side area using a tie strap.
- Step 6: Test the harness, simply turn your headlight switch on and the fog's lights will come on.
- Step 7: Reinstall the air cleaner and secure all wires.

Thank you Gen5DIY