

INSTALLATION GUIDE: PLASTERBOARD

Breathaplasta is ideal as a healthy skim coat applied directly to conventional gypsum plasterboard without primer. Breathaplasta is a quick and easy lime plaster. It's simple to use and sets within an hour.

Important notes for use on plasterboard:

- Ensure plasterboard is conventional gypsum plasterboard (ivory coloured paper).
- Specialist plasterboard may need a primer to be used before plastering. For example: moisture resistant (green) and fire resistant (pink).



Add 1 x 20kg bag of Breathaplasta to approx. 10 - 11 litres of clean water



Good for our buildings



Good for our health



Good for our environment



Mix the plaster using a paddle mix for at least 60 seconds



Apply at least 2 coats of plaster to all surfaces. Each coat should be approximately 2mm thick



Setting time per coat of Breathaplasta is approx. 45 - 60 minutes



Run a clean trowel over the surface of the plaster for a smooth finish. Use a sponge float for more textured finishes.



Moisten the surface of the plaster with a fine mist spray bottle to help trowel to a smooth finish

Equipment Required:

Breathaplasta, clean water and brush or water mister, hawk, trowel and plastering tools.

Surface preparation:

No treatment or priming is required before applying plaster to conventional plasterboard. Seek advice from Adaptavate if using specialist plasterboard such as moisture resistant board (green paper) or fire resistant board (pink paper) and other wallboard types.

Recommended plaster thickness:

Approximately 4mm total thickness.

Recommended plaster application:

1. Base coat 2mm.
2. Top coat 2mm
3. Moisten top coat using a fine mist spray bottle to help trowel to a smooth finish.

Coverage per 20kg bag:

Approx. 5 square metres at 4mm thickness

Setting time per coat:

Approx. 45 - 60 minutes