



Wall: Timber construction *Windtight and rainproof on the outside*

Penetrating the facade membrane for closed facades



- Cut off Wigluv 20/40: leave approx. 4 cm on both sides
- Separate the narrow backing strip and affix in the corner
- Separate the wide backing strip and press on firmly
- Cut the corner at 45°



- Fold over
- Press on
- Repeat on each side of the penetration



How it should look:

- Square penetration sealed windtight using Wigluv 20/40.



Wigluv® 20/40

P. 129