



SPREAD

With the help of a notched 4mm notched trowel, spread Sto Bonding & Pointing Mortar on an area of approximately 1sq.m. Do not spread on wider area due to fast drying rate of the adhesive. Thickness of the layer should be around 2 mm. It is recommended to start from top of the wall and work your way to the bottom.



PRESS

Press the flexible Sto Ecoshape slip to the freshly applied adhesive and leave 12-14 mm space between the brick slips. You must carefully press over its entire surface immediately after the application.



CUT

Using rigid scissors, cut the brick slips as needed to fit your layout.



CORNER

Apply our pre-shaped 90° or 135° corners as you would the flat slips.



POINT

After pressing the brick slips into place, the fresh excess adhesive must be removed by using a 12mm wide brush. It is very important to pay attention to the execution of sealing the joints to block the water access between the brick slips and the adhesive. Also pay close attention and cover the edges of the brick slips as they must be fully coated with the adhesive.