INSTALLATION STEPS

Step1

Gather all 4 of the extrusions and lay them out on a flat surface. The extrusions will be linked together using the tool free locking mechanisms.



Step 4

Press the lever down completely on the inserted side of the locking mechanism.



Step 7

Make sure the extrusions are flush where the corners meet up.



Step 10

The adjacent extrusions should be parallel to each other like the example below.



Step 2

Take (1) locking mechanism and (1) extrusion. Make sure the locking mechanism is in the unlocked position with the lever folded in.





Step 5

Fully locked position shown above.



Step 8

Push and lock the 2nd lever on the locking mechanism.



Step 11

Insert the remaining locking mechanisms into the last extrusion. Slide the last extrusion in, then push the remaining levers to lock and complete the frame.



Step 3

Insert the locking mechanism into the slot of the extrusion piece completely, as shown above. Insertion begins at either end of the of the extrusion.





Step 6

Slide on an extrusion to the adjacent corner.



Step 9

One corner is now complete. Repeat the same process for the opposite corner.



Step 12

The frame is now ready to be fitted with the graphic.

