

WIRING DIAGRAM FOR SINGLE BASSBAR™



Directions: Tie white & green wires together (Ground) and solder to volume pot.
Take orange wires (hot) and connect to switch where noted by blue arrows.

250K pots recommended for better tone.
.022mfd cap recommended

FOR FOLLOWING BASS PICKUPS

- LACE TRANSENSOR
- LACE SENSOR
- LACE BASSBAR

