

WIRING DIAGRAM FOR J-BASS MAN O WAR

Directions: Tie white & green wires together, (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone
.022 mfd cap recommended

