

WIRING DIAGRAM FOR PRECISION BASS

Directions: Tie white and green wires together (ground) and solder to volume pot
Take orange wires (hot) and connect to switch.

250k pots recommended for better tone
.022mfd cap recommended

Lace Sensor Man-O-War P Bass

