WIRING DIAGRAM FOR ALUMA PRECISION BASS

Directions: Tie white and green wires together (ground) and solder to volume pot Take orange wires (hot) and connect to switch.

250k pots recommended for better tone .022mfd cap recommended

Note:

Each Aluma - P coil is an independent humbucking Alumitone To change phasing: Tie orange and green leads together and use white/black striped for hot.



