

WIRING DIAGRAM FOR STRAT®

Directions: Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone.

.022 mfd cap recommended.

For Lace single coil and AlumiTone single coil pickups.

