

WIRING DIAGRAM FOR TELE®

Directions: Tie white & green wires together (Ground) and solder to volume pot.
Take orange wires (hot) and connect to switch where noted by blue arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone.
.022 mfd cap recommended.

For Lace T-100 and T-150 pickups only.

