

FITTING INSTRUCTIONS FOR CRASH PROTECTORS CP0213 KAWASAKI GTR 1400 07'



LHS



RHS

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – the rubber washers should be thrown away!

Nearside/LHS (Left Hand-Side as you sit on the bike)

- Remove the fairing panel.
- Remove the engine mount bolt (10mm).
- Remove the 8mm bolt directly above engine mount bolt.
- Take the smaller of the two aluminium blocks supplied and offer up.
- Take the M10 x 80 cap head bolt slide one of the 10mm washers up to the head of the bolt and fit through the block (bottom hole) and into the bike.
- Take one of the two M8 x 40mm cap head bolts and slide one of the 8mm washers up to the head of the bolt and fit it through the block (top hole) and into the bike.
- Tighten both bolts.
- Insert one of the supplied M12 bolts into the bolt hole and paint the exposed end.
- Offer the fairing back into position so that the paint marks the position inside the fairing.
- Using a 28mm tank cutter/cone cutter, drill through the fairing with the pilot drill using the mark made by the paint to find the centre. Replace the fairing and ensure that the pilot hole is in the correct position. Remove the fairing and support it. Drill through carefully from the outside with the tank cutter.
- Take the longer of the two spacer blocks, and slide onto the end of the block that you have just fitted.
- Refit the fairing panel.



- Take the M12 x 100 hex head bolt and slide one of the 12mm washers up to the head of the bolt.
- Fit the bolt through one of the crash protectors and fit to the R&G block and tighten do not exceed 40nm.

Offside/RHS (Right Hand-Side as you sit on the bike)

- Remove the fairing panel.
- Remove the engine mount bolt (10mm).
- Remove the 8mm bolt directly above engine mount bolt.
- Take the larger of the two aluminium blocks supplied and offer up.
- Take the M10 x 60 cap head bolt slide one of the 10mm washers up to the head of the bolt and fit through the block (bottom hole) and through the small spacer supplied and into the bike.
- Take one of the two M8 x 40mm cap head bolts and slide one of the 8mm washers up to the head of the bolt and fit it through the block (top hole) and into the bike
- Tighten both bolts.
- Insert one of the supplied M12 bolts into the bolt hole and paint the exposed end.
- Offer the fairing back into position so that the paint marks the position inside the fairing.
- Using a 28mm tank cutter/cone cutter, drill through the fairing with the pilot drill using the mark made by the paint to find the centre. Replace the fairing and ensure that the pilot hole is in the correct position. Remove the fairing and support it. Drill through carefully from the outside with the tank cutter.
- Take the shorter of the two spacer blocks, and slide on to the end of the block that you have just fitted.
- Refit fairing panel
- Take the M12 x 90 hex head bolt and slide one of the 12mm washers up to the head of the bolt
- Fit the bolt through one of the crash protectors and fit to the R&G block and tighten do not exceed 40nm

Due to the risk of cross-threading of bolts etc; we always recommend that our products be fitted by one of our official dealers or a qualified mechanic.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.