

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### DUCATI 959/1299

#### MIRROR BLOCK OFF TURN SIGNALS

- 1 Remove two 4mm allen bolts
- 2 Unplug stock connector
- 3 Slide bolts through block off and into front fairing, plugging in new turn signal
- 4 With a pair of pliers, slide connector and wiring back into fairing
- 5 Slide new bolt through block off plate and tighten nut on back side