NEW OCECYCLES INSTALLATION INSTRUCTIONS

DUCATI SUPERSPORT 939

FRONT TURN SIGNALS

- (1) Remove (3) bolts on windshield (picture 1)
- 2 Slide windshield off and slide new turn signals into place
- Plug in connectors (if necessary)
- 4 Using stock bolts, re-install windshield

