

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### DUCATI SUPERSPORT 939

#### MIRROR BLOCK OFF PLATES

- 1 Remove (2) M6 bolts and slide off stock mirrors
- 2 Re-use stock bolts and supplied star nuts and thread back into position (picture 1)
- 3 Take plate with rubber nut insert and slide in behind fairing (picture 2)
- 4 Re-use stock gasket, take top plate, and thread torx bolt (picture 3)

