

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### DUCATI XDIAVEL

#### FRONT TURN SIGNALS

- 1 Unscrew and remove lenses off stock turn signals (Picture 1)
- 2 Unplug harness and slide out from stock turn signals (Picture 2)
- 3 With a 4mm allen key, loosen clamps around forks (Picture 3)
- 4 Before removing clamp, you must remove two nuts on the back of the headlight and slide the headlight off (Picture 4)
- 5 Now you may remove the plastic fork clamps
- 6 Take NRC turn signal bracket and slide top tabs over the bolts that were just loosened (Picture 5)
- 7 Reinstall headlight by tightening the nuts previously removed
- 8 With provided shrink tube, plug in NRC turn signals to stock harness and seal connections (Picture 2)
  - Red NRC wire to Positive connector
  - Black NRC wire to Ground connector
  - Center connector is positive / Outer connector is ground

