



Fitting Instructions for CP0149BL Crash Protectors Ducati Monster ('97 - '00)



PLEASE NOTE THAT THE WAY THE KIT IS PACKED DOES NOT NECESSARILY REPRESENT THE WAY OF MOUNTING TO THE BIKE

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

- Undo the engine bar located mid engine
- Take R&G tie bar, remove bobbins, then remove one end (22mm spanner fits) on the stainless steel extension.
- The turned-down section goes in and sits down into the frame.
- Push bar right the way through engine (in bolt's original position).
- Put on end of tie bar and tighten extension.
- Refit fairings
- Fit bobbins.
- Tighten bolt until you feel some compression from inside the protector. Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not overtighten as damage can occur to the bike. Do not exceed 40nm of torque.

Due to the risk of cross-threading of bolts etc; we always recommend that our products be fitted by one of our official dealers or a qualified mechanic.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



**Instructions de montage pour CP0149BL Protections crash
Ducati Monster ('97 – '00)**



LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR LA MOTO.

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées*.

- Défaire l'axe moteur logée à mi hauteur du moteur.
- Prendre l'axe R&G, enlever les bobines, puis enlever une extrémité (pince de 22mm) sur l'extension en acier inoxydable.
- la section retournée vers le bas va à l'intérieur et se place dans le cadre.
- Pousser l'axe à travers le moteur (dans la position du boulon d'origine).
- Une fois au bout, serrer.
- Remettre les carénages.
- Installer les bobines.
- Serrer le boulon jusqu'à ce que vous sentiez une compression de l'intérieur de la protection. Tournez un peu plus de façon à ce que vous sentiez la compression augmenter un peu plus. Appliquez un quart de tour. Ne pas trop bloquer, cela pourrait endommager la moto. Ne pas excéder 40Nm de couple.

Du fait des risques d'endommagement engendrés par l'installation de la protection, nous vous recommandons de faire effectuer le montage par un professionnel.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com