



## ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTION

| ART.  | DESCRIZIONE / NAME   |
|-------|--|
| TT326 | KIT TAPPI TELAIO – FRAME CAPS SET                              |
|       | DUCATI: HYPERMOTARD 821 – HYPERMOTARD SP 821 – HYPERSTRADA 821 |

Si consiglia di far eseguire il montaggio dei componenti applicati ad un'officina specializzata - We recommend having the accessori parts fitted by a specialist workshop



| POS.                      | MISURA DEL TAPPO – CAP SIZE |      |          |
|---------------------------|-----------------------------|------|----------|
|                           | A                           | B    | C        |
| LATO FRENO<br>SIDE BRAKE  | 27.5                        | 23.0 | SPECIALE |
| LATO CAMBIO<br>SIDE SHIFT | 27.5                        | 22.5 | SPECIAL  |

### ISTRUZIONI

- Sgrassare il foro di alloggiamento (Pos. A-B),
- Lubrificare la sede che accoglie la testa della vite (X) presente sul tappo
- Assicurare il fissaggio delle viti del tappo C con frenafili a media tenuta

### INSTRUCTIONS

- *Degrease the bore again (A-B),*
- *Lubricate the seat (X) that accommodates the head of the screw on cap*
- *Ensure it is screwed on the cap C with medium strength Loctite sealing*

**ATTENZIONE:** Il prodotto in questione potrebbe non essere conforme al codice stradale o alle leggi vigenti in alcuni paesi e quindi utilizzabili solo in aree private e/o chiuse al traffico  
**WARNING:** The product in question may not comply with local road rules and regulations and are therefore only be used in private areas and / or areas closed to traffic