



Denmark Retro Hanging Pendant Lights Installation Instructions

1. Mount the Mounting plate (AA) to the outlet box using the two outlet Box Screws(FF).
2. Connect the copper wire from the Canopy (A) to the mounting plate (AA) by securing it with the pre-installed ground screw(BB). Then connect the copper wire from fixture and the ground wire from outlet box.
3. Connect the Ribbed wire(label show as N) from the fixture to the white wire(neutral wire) from the outlet box.
4. Connect the Smooth wire(label show as H) from the fixture to the black wire(live wire) from the outlet box.
5. Cover the three connections using the three wire nuts(EE). Wrap the three wire connections with electrical tape for a more secure connection.
6. Position the wire back inside the outlet box.
7. Lift the Canopy(A) up to the ceiling, and secure with two Cap nuts(DD).
8. Screw light bulb (Using G9 Bulb not included) into the socket.
9. Raise the GLASS SHADE (B) into the socket, rotate the Glass to fix it on the socket.

