

# How to use the Wire Anchor



# Recessed installation of Wire Anchor



Mark Fence strand spacing



Pre-mark spade bit 10-12mm as show above



Drill to pre-marked depth to take anchor



Using centre mark, drill through the post 8mm-10mm



**Rebated and 10mm hole  
ready for upsizing**



**Using 16mm bit upsize hole  
to a depth of 50mm**



**The strainer post is now  
ready to take the anchor**



**Anchor installed, recessed  
into strainer post**

# Fitting wire anchor, without recessing



Mark Fence strand spacing



Using 8mm-10mm bit drill through post



Upsize hole with 16mm drill bit 50mm deep



post is ready to accept anchor

# USING THE STRAINER



Put strand through grabbing point of strainer



And pull handle down