



FORD RANGER PX

INSTALL SUPPLIED CHASSIS BRACKET TO EXISTING CHASSIS HOLES WITH HANDLE NUTS SUPPLIED. POSITION RESERVOIR AND HOSE FOR CLEARANCE TO CHASSIS AND TIRE.



HOSE RUNNING FORWARD AND INWARD WITH A LITTLE CLEARANCE TO TIE-ROD BOOT WITH STEERING AT FULL LOCK IN BOTH DIRECTIONS AND SUSPENSION AT FULL DROOP. P-CLAMP TO MOUNT BOLT