



**Wrap duct tape around the ink insert of your marker and firmly pull/twist the insert out.**



**Gently insert and line up the Mk-ER into the empty marker body.**



**Firmly press/twist the Mk-ER down until the last ridge is flush w/ marker body.**



**Press marker cap on with firm pressure until cap seats fully into place.**