



**Genesis G80 5.0  
BIG MOUTH Ram Air Intake  
Installation Guide**



Please review this document before attempting installation.

You will need basic hand tools and 1-1.5 hours of installation time.

This product reuses the OEM hardware.

| Description       | Qty in kit |
|-------------------|------------|
|                   | #          |
| 16" long zip ties | 4          |


## Bumper Removal

Remove the shroud by pushing down on the center pin of the pop-up clips and extracting them with a pry tool.



## Bumper Removal

After removing the shroud, remove the top 4 screws (10mm) that attach the bumper to the chassis



## Bumper Removal

Remove the 3 pop-up clips and 1 screw (8mm) that lie in the wheel well





## Bumper Removal

Remove 6 pop-up clips (no screws) that trace the edge of the bumper such as the ones indicated below.




## Bumper Removal

As the bumper gets pulled off, take notice of the indicated wiring harness connector. To remove, pull back on the lever shown below. Once it swivels about entirely, pull to disconnect.



# Stock Components Removal

To remove the OEM components, start by removing the air ducts first and the radiator shroud afterwards.








## Stock Inlet Removal

To remove the OEM inlets, there are 3 (10mm) screws that need to be removed. You will need a 6" extension to reach the recessed screw. **Hold on to these, some of them will be reused.**




## Stock Inlet Removal

Use a non-marring pry tool to remove the pop-up clip at the top of the inlet. Proceed by removing the inlet.



## Shroud Removal

Remove the following screws and repeat for the other half of the shroud.






## Shroud Removal

From the backside of the shroud, carefully undo the clips holding the wire loom by pinching as shown in the image. There are numerous clips along the shroud.


Once these have been undone, the shroud should be free to remove.





## Important Notice



The installations that follow this slide only use **coarse-thread** hardware which you extracted, shown circled in green. The threads are much larger and spaced out. Also, the coarse-thread hardware ends with a sharp point.



IMPORTANT FOR NEXT SLIDE!!!

## Big Mouth Install

Carefully slide the big mouth intakes over the stock ports and ensure the bolt holes line up. **Fasten using OEM coarse-thread hardware. Do not torque down hard.**



**DO NOT CROSS-THREAD AND MAKE SURE NOT TO OVERTORQUE.**



# Reinstall Bumper

Re-install the bumper the same way it was removed and ENJOY!

