



# **S550 Mustang Diffuser Fins Installation**



## ***Installation***

Observe the following image and take note of the approximate spacing of the fins. Some people prefer them to be evenly spaced and some prefer them to be asymmetric, it's up to you on placement. Before you remove the protective strip from the tape, **MAKE SURE** you have the alignment perfect. You will not be able to remove the fins once they are pressed into place, the tape will not be able to be re-used. It is best to have a friend give you alignment feedback while you are installing them 'without tape', use a marker to ensure you won't forget your placement once you've settled on a good spot for the fin. Remove the protective layer from the tape and **FIRMLY** press the fin onto the bumper from both sides, you can reach around and use your hand to push on the inside of the bumper while pushing up on the fin, this will close any gap and ensure a strong bond.

