

## DASHBOARD INLAY DECAL INSTALLATION

Thank you for your order!

### **Please read the installation instruction completely before applying your vinyl decals.**

Proper cleaning and preparation of the surface prior to vinyl application is critical to the success of the decals. The following cleaning and surface preparation conditions must be followed immediately prior to application. Failure to adhere to these requirements can cause adhesion loss and therefore reduce the durability and performance of the decals. Use denatured or isopropyl alcohol (rubbing alcohol) and a lint free soft towel to clean the surface of the emblems. Ensure that the emblems are absolutely clean before applying the decals.

These decals are installed dry via transfer tape. Slowly peel the transfer tape from the backing paper, ensuring that the vinyl letter separates from the paper and stays on the transfer tape.

Holding the left and right sides of the transfer tape, center the decal over the corresponding letter and slowly lay it down on the surface of the emblem. Do this very carefully and slowly because once the decal contacts the surface of the emblem it cannot be removed without damaging the decal. Don't worry if it is not exactly centered. Slight variations in the decal positions are rarely noticeable.

Firmly press down on the surface of the transfer tape to adhere the decal to the letter.

Slowly peel the transfer tape away at a 180 degree angle, ensuring that the vinyl does not lift up with the transfer tape.

Use your fingers to press down on the edges of the decals to ensure they have adhered properly.

Repeat with the remaining letters.

Enjoy the new look of your RAM 1500!

Please don't hesitate to contact us if you have any issues or questions about installing these decals on your truck, or if you need additional letters.

Thanks!

Rich

Support@TVDVinylDecals.com