

4Runner Radar Cover Decal Application

Thank you for your order!

Please read the installation instruction completely before applying your vinyl decal.

This installation should take about 15 minutes. This can be a challenging installation for some. Just take your time, work in a well-lighted area (with no wind!), on a cool surface, and thoroughly understand the steps below before attempting the installation.

Proper cleaning and preparation of the surface prior to vinyl application is critical to the success of the decal. The following cleaning and surface preparation conditions must be followed immediately prior to application. Failure to adhere to these requirements can cause adhesion loss and therefore reduce the durability and performance of the decals. Use an automotive cleaner to clean the radar panel of any bugs and debris that may exist. DO NOT use denatured or isopropyl alcohol (rubbing alcohol) as this may discolor the plastic. Ensure that the entire panel is absolutely clean before applying the decal.

The radar panel vinyl decals is applied dry via the supplied transfer tape. Slowly peel the transfer tape from the backing paper, ensuring that the vinyl separates from the paper and stays on the transfer tape.

Holding the left and right sides of the transfer tape, align the decal with the top left corner and top edge of the panel, ensuring the decal is oriented properly to match the surrounding grille sections. Press the decal down across the surface of the panel carefully and slowly. Once the decal contacts the surface of the panel it cannot be removed without damaging the vinyl. Don't worry if it is not exactly centered. Slight variations in the decal positions are rarely noticeable.

Firmly rub the edge of a credit card or other plastic edge across the surface of the transfer tape to press the decal onto the radar cover. Do this only when the transfer tape is still applied.

Wait about 10-15 minutes to allow the adhesive to bond to the surface of the panel, then slowly peel the transfer tape back at a 180 degree angle (don't lift it up), ensuring that the vinyl does not lift up with the transfer tape.

Use your fingers to press down on the edges of the decals to ensure they have adhered properly. DO NOT use a plastic edge on the decal after the transfer tape has been removed or you may damage the decal.

Enjoy the new look of your 4Runner!

Please allow 24 hours for the vinyl decal to completely adhere to vehicle. Do not get the vinyl decal wet during this time.

Please don't hesitate to contact us if you have any issues or questions about installing this decal on your truck, or if you need a replacement.

Thanks!

Rich
Support@TVDvinyldecals.com