

FJ Cruiser Emblem Inlay Decal Installation

Thank you for your order!

Please read the installation instruction completely before applying your vinyl decals.

This installation should take about 45 minutes. This can be a challenging installation for some. Just take your time, work in a well-lighted area (with no wind!), on a cool surface, and thoroughly understand the steps below before attempting the installation. Here is what you will need:

Small bowl
Water
Dish soap
Soft towel
Rubbing Alcohol

Proper cleaning and preparation of the surface prior to vinyl application is critical to the success of the decals. The following cleaning and surface preparation conditions must be followed immediately prior to application. Failure to adhere to these requirements can cause adhesion loss and therefore reduce the durability and performance of the decals. Use denatured or isopropyl alcohol (rubbing alcohol) and a lint free soft towel to clean the surface of the emblems. Ensure that the emblems are absolutely clean before applying the decals.

The emblem inlay decals are installed dry via transfer tape. Slowly peel the transfer tape from the backing paper, ensuring that the vinyl letter separates from the paper and stays on the transfer tape.

Holding the left and right sides of the transfer tape, center the decal over the corresponding letter and slowly lay it down on the surface of the badge so that the chrome is visible around all the sides of the decal. Do this very carefully and slowly because once the decal contacts the surface of the badge it cannot be removed without damaging the decal. Don't worry if it is not exactly centered. Slight variations in the decal positions are rarely noticeable.

Firmly press down on the surface of the transfer tape to adhere the decal to the emblem. Do this only when the transfer tape is still applied.

Wait about 5-minutes then slowly peel the transfer tape away at a 180 degree angle, ensuring that the vinyl does not lift up with the transfer tape.

Use your fingers to press down on the edges of the decals to ensure they have adhered properly.

Proceed to the next letter.

Enjoy the new look of your FJ Cruiser!

Please allow 24 hours for the vinyl decals to completely adhere to vehicle. Do not get the vinyl decals wet during this time.

Please don't hesitate to contact us if you have any issues or questions about installing these decals on your truck, or if you need additional letters.

Thanks again for your purchase!

Rich
Support@TVDVinylDecals.com