

## TRD Wheel Center Cap Decal Installation

Thank you for your order. Please read the installation instruction completely before applying your vinyl decals.

This installation should take about 30 minutes. Here is what you will need:

Small bowl  
Water  
Dish soap  
Masking Tape  
Soft towel  
Tweezers or credit card

Proper cleaning and preparation of the surface prior to vinyl application is critical to the success of the decals. Remove the caps from the wheels and thoroughly clean them with soap and water.

To ensure proper alignment of the decals over the TRD letters on the center cap, we recommend the “wet” application method.

1. Make a soap solution by filling a small bowl with water and adding 2 drops of dish soap for every 6 oz. of water.
2. Dip your finger in the soap solution and spread the solution over the T on the center cap, ensuring that the entire letter is wet.
3. Attach a small piece of masking tape or transfer tape to a corner of the T decal and gently pull up to separate the vinyl from the paper backing.
4. Dip the entire decal and tape in the soap solution.
5. Carefully remove the tape from the decal and lay the decal over the T on the center cap. It should “float” on the soap solution over the letter on the center cap. The soap solution will help move the decal to the desired position before the decal adheres to the center cap.
6. Gently nudge the T into position with your fingernail, tweezers, or the edge of a credit card to completely cover the original red color. Blot away any excess water with the soft towel to prevent the decal from moving too much. When are you satisfied with the position of the decal anchor the leg or one of the arms of the T with your thumb and slowly roll your thumb over the decal to push out the water out from under the decal. Do this lightly at first to allow you to reposition the decal as needed as you squeegee it with your thumb. The vinyl will quickly adhere to the center cap as the moisture is removed with each pass of your thumb so be sure it is positioned correctly and make several light passes over the decal. Once adhered to the center cap the decal cannot be removed without destroying it. Please note that a small sliver of red may still show on some of the edges. This is due to the inward curvature of the indented letters and will not be noticeable from a standing distance from the wheels.
7. Gently blot the excess moisture from the area with a soft towel and make several more gentle passes with your thumbs until there is no more moisture coming out from under the vinyl decal.
8. Repeat these steps for the remaining letters for each wheel.
9. After all the decals have been applied return to the first decal and use a bit more pressure with your thumbs to push out any remaining moisture then blot it with the soft towel. Repeat this final step on the remaining decals.

Please allow 24 hours for the vinyl decals to completely dry and properly adhere to the center caps before reinstalling the center caps on your wheels. Do not get the vinyl decals wet during this time.

Please don't hesitate to contact us if you have any questions about installing them on your wheels.

Rich  
Support@TVDVinylDecals.com