



# Viba Hardware Acrylic Lite Craftsman door

## Assembly instructions

Hardware is provided with your door. Do not use glue or other hardware in assembly.

# Staining and finishing

## If staining

- stain door before you assemble it
- assemble and then apply topcoat

## If painting

- prime door with shellac based prime
- apply paint

# Step 1 – form the “C”



- All joints are lettered.
- You will need a t-25 torx bit from your local hardware store.
- Install screws to form a large letter “C”

## Step 2 - Assembling the first lite and the middle rail.



- REMOVE THE PLASTIC ON THE ACRYLIC FIRST!
- Insert the acrylic lite in the upper corner and tap the middle vertical rail into place.

# Step 3- The middle horizontal



- Then insert the middle horizontal rail.
- You may need to tap the middle vertical rail slightly to get it to parallel to the outside rails.

# Step 4 – the panel pieces



- Insert the panel pieces in the main body of the door.

# Step 5 – the other side



- Now it is time to install the other side.
- Line up the holes, number to number and tighten
- The middle horizontal will not fully seat on its own, you will need to tap the outside rail with a rubber mallet.

Step 6 – door is ready for hardware.

